

## Universaldamask *Universal CV-Boot*



**CDX**  
DRIVELINE  
Monteringsanvisning  
*Mounting instruction*

- Demontera drivknuten och rengör noga drivaxeln och drivknuten från fett och smuts.



*Dismount the CV-Joint and thoroughly remove grease and dirt from the driveshaft and the CV-Joint.*

- Skär av damasken till lämplig diameter för drivaxeln och drivknut.
- Trä på damasken på drivaxeln.
- Montera tillbaka drivknuten på drivaxeln. Det är viktigt att gängor och splines inte skadas vid monteringen.
- Applicera det medföljande fettet i damasken.

*Cut the boot to suitable diameter for driveshaft and CV-Joint.*

*Slide the boot over the driveshaft.*

*Mount the CV-Joint back on the driveshaft. It is important not to damage threads and splines when mounting the CV-Joint.*

*Apply the enclosed grease into the CV-Boot.*



- Dra damasken över drivknuten.

*Slide the boot over the CV-Joint.*



- Fäst damasken med medföljande klammer på drivknut och drivaxel.



*Fasten the boot with the enclosed clamps on the CV-Joint and the driveshaft.*